

Hand Wave Sensor Button For Touchless Switch With Microwave Technology



WS-R

What is Hand Wave Sensor Button?

Hand Wave Sensor Button It is activated by hands waving.

After correctly connected this sensor with your power supply and access control system, when you wave your hand at the sensor, the door will turn on automatically.

Specifications

S4A Model No.	WS-R	Operation Frequency	38KHZ
Supply power	AC/DC 12V~36V	Working environment humidity	-20℃~45℃
Static parameter	DC12V 22mA	Dimension	113x63x20mm
Action current	DC12V 55mA	Fixed way	Fixed with hidden screw
Transmit distance	1~15CM adjustable	Total Weight	108G

Dimensions

